

Instructions For Upgrading The Headtrip™ Firmware

1. Connect the player to your computer.
2. Click the Removable Disk under My Computer.
3. Copy all needed files from the player to your computer
4. Copy the file of "\$norfla\$.ugr" into Removable Disk.
5. Please note that the file name of "\$norfla\$.ugr" cannot be changed.
6. After copying the file of "\$norfla\$.ugr" into Removable Disk, unplug the player by safety removal procedures.
7. Wait until the player finish startup procedure.
 (About 20-30 seconds or until the LED light is off)
8. Connect the player to your computer again.
9. Format the player with FAT file system.
(Not FAT32, use FAT only!)
10. Copy the file of "\$nanfla\$.ugr" into Removable Disk.
11. Please note that the file name of "\$nanfla\$.ugr" cannot be changed.
12. Once you unplug the player, the firmware will be upgraded automatically.
13. Wait until the player finish startup procedure.
(About 20-30 seconds or until the LED light is off)